

Origin Residential Doors
Operating Instructions

### Standard Locking

# Opening the door

#### From the outside...

#### 1.

Insert the key into the barrel and rotate 360° towards the centre of the door

#### 2.

Operate the lever handle fully downwards to disengage all locking points.

#### 3.

Rotate the key until the latch is released and open the door.

#### 4.

Remove the key.

**N.B** If using a magnetic coded key, the key will insert and remove horizontally.

#### From the inside...

#### 1.

Insert the key into the barrel (if not a thumb turn) and rotate 360° towards the centre of the door.

#### 2.

Remove the key.

#### 3.

Operate the lever handle fully downwards to disengage all locking points and open the door.

**N.B** If using a magnetic coded key, the key will insert and remove horizontally.

## Closing the door

#### 1.

Close the door to the point at which the latch engages and it is held against the frame.

#### 2.

Lift the lever handle fully upwards to engage all locking points.

#### 3.

Insert the key into the barrel (if not a thumb turn) and rotate 360° away from the centre of the door.

#### 4

Remove the key.

**N.B** If using a magnetic coded key, the key will insert and remove horizontally.

### Automatic Lock

# Opening the door

#### 1.

Insert the key into the barrel (if not a thumb turn) and rotate fully towards the centre of the door to disengage all locking points and open the door.

**N.B** It may be necessary to apply a little pressure to the door whilst turning the key to counteract the force from the door seals.

N.B If using a magnetic coded key, the key will insert and remove horizontally.

**2.** Remove Key.

## Closing the door

- **1.** Close the door fully until all locking points have engaged.
- 2. Insert the key (if not a thumb turn) and rotate 360° away from the centre of the door.
- 3. Remove the key.
- **N.B** If using a magnetic coded key, the key. will insert and remove horizontally.





## Helpful hints and tips:

Always remove the key from the lock to prevent damage to the lock.

Origin accept no warranty claims for damage caused by keys being left in the locks.

### Maintenance Instructions

Your Origin Doors contain mechanical moving parts that will need to be lubricated periodically. This will include the hinges, multipoint lock and handles. Lubricate using silicone spray or grease and wipe away any excess with a non-abrasive cloth.

## Routine Care of your Origin Doors

#### Powder coated aluminium profile

Use a light, soapy solution (such as a diluted baby bath product) and non-abrasive cloth to wipe dirt from the doors. Washing up liquid is not recommended, and do not use solvent based cleaning products. Please also refrain from using an abrasive cloth such as a scouring pad as the doors can be scratched.

In salt water environments, the external surface of the doors should be washed down with fresh water on a weekly basis as it is common for salt deposits to build up.

#### "QLon" seals

Use a light, soapy solution and non-abrasive cloth to gently clean these. Do not use solvent based cleaning products on the seals.



If you would like any aspect of the door operation explaining to you, please call or email a member of the team using the details below.